
FUSIXIN MICRO HUB 2.0 INSTALLATION INSTRUCTIONS



A ENSURE FIREARM IS UNLOADED

- 1 Configure Micro Hub with additional FUSION™ accessories and or OEM lights and lasers utilizing the included hardware. Use 10-32 Screws to attach other FUSION™ components, and 8-32 Screws to attach Surefire™ and similar Scout footprint lights. Finger Tight, then 1/8 1/4 turn further. D0 NOT EXCEED 18 IN-LBS.
- Using the included clamp and screws, secure assembly to M1913 Picatinny Rail. Finger Tight, then 1/8 1/4 turn further. DO NOT EXCEED 18 IN-LBS.



FUSIXIN MICRO HUB 2.0 INSTALLATION INSTRUCTIONS



A ENSURE FIREARM IS UNLOADED

- FUSION™ Micro Hub is the base component for the entire FUSION™ parts suite. Direct mount compatible with:
 - -Surefire™ Scout Series Lights
 - -Modlite™ Lights
 - -Streamlight™ PRO-TAC Series Lights
 - -Steiner™ DBAL Series Lasers

