

FUSION™ MICRO HUB 2.0

INSTALLATION INSTRUCTIONS




⚠️ ENSURE FIREARM IS UNLOADED

⚠️ WARNING: Over-torquing fasteners can damage your mount and will not be covered by warranty.

1 Configure Micro Hub with additional FUSION™ accessories and/or OEM lights and lasers utilizing the included hardware. Use 10-32 Screws to attach other FUSION™ components, and 8-32 Screws to attach Surefire™ and similar Scout footprint lights. Secure screws using a T15 bit driver. Lightly snug all screws before applying final torque to any. **TORQUE TO 16 IN-LBS.**

2 Using the included clamp and screws, secure assembly to M1913 Picatinny Rail. Secure screws using a T15 bit driver. Lightly snug all screws before applying final torque to any. **TORQUE TO 16 IN-LBS.**



FUSION™ MICRO HUB 2.0

INSTALLATION INSTRUCTIONS



⚠ ENSURE FIREARM IS UNLOADED

3 FUSION™ Micro Hub is the base component for the entire FUSION™ parts suite. Direct mount compatible with:

- Surefire™ Scout Series Lights
- Modlite™ Lights
- Streamlight™ PRO-TAC Series Lights
- Steiner™ DBAL Series Lasers

